## Disassembly and Recycling instructions

Knú Comfort encourages you to recycle whenever possible



**Stacking:** Conceive Series (Discontinued)

## What to expect:

**Disassembly Time:** 15-20 minutes per chair (General)

(allow additional 20-30 minutes for detailed component disassembly)

#### **Tools needed:**

Personal Protective Equipment (Safety Glasses) Screwdrivers (Phillips #2 - #3) Utility Knife

#### **Material Content:**

Metal (& steel)
Poly Foam
Textile (fabric/vinyl)
Polyethylene Molded Plastic

### **Component Content:**

Metal Frame: (Steel)

<u>Upholstered Back</u> (Polyethylene Molded Plastic, poly foam, textile w/staples (fabric/vinyl), mounting brackets (steel)

<u>Upholstered Seat:</u> (Polyethylene Molded Plastic, poly foam, textile w/staples (fabric/vinyl)

Hardware: (bolts/screws (steel)

# **Stacking Series:** (Concieve)

## **Seat Removal: (typical)**

 Use screwdriver (phillips) to remove (4) mounting bolts and remove the upholstered seat and bottom plastic seat frame cover

## **Back Removal: (typical)**

Place unit "right side up" and use screwdriver to remove (2) mounting bolts



 Use mallet to hammer down along the bottom center edge of back panel to free back panel and remove



# Caster Removal: (if necessary)

With unit "up side down", Use mallet and tap out each caster

