

Fold Down Sleepers: including; Florin, Harmony, Max, and Tranquility Series

What to expect:

Disassembly Time: 15-20 minutes per chair (General)
(allow additional 20-30 minutes for detailed component disassembly)

Tools needed:

- Personal Protective Equipment (Safety Glasses)
- Wrenches/Ratchet w/sockets (7/16")
- Torx Bit (T30)
- Screwdrivers (Phillips #2 - #3)
- Utility Knife
- Rubber Mallet

Material Content:

- Wood
- Metal (♻️ steel)
- Poly Foam
- Textile (fabric/vinyl)
- Polyethylene Plastic

Component Content:

- Upholstered Arms: (plywood frame w/nuts and staples, poly foam, textile w/staples (fabric/vinyl), arm caps (solid wood or urethane/steel)
- Upholstered Outside Back: (plywood frame w/t-nuts, poly foam, textile w/staples (fabric/vinyl), mounting brackets (steel)
- Folded Cushion Back: (poly foam, textile (fabric/vinyl)
- Upholstered Seat: (plywood w/t-nuts (steel), poly foam, textile w/staples (fabric/vinyl)
- Chassis Rails: (♻️ steel, plastic)
- Pull-out Drawer/Drawer Assembly: (plywood frame w/staple, drawer glides (♻️ steel)
- Hardware: (bolts/screws (♻️ steel)

Fold Down Sleeper:


Drawer Removal: (typical)

- Pull out each drawer assembly, lift the front of the drawer in order to separate the drawer assembly from drawer glide
.....
- Use screwdriver (*phillips*) to remove (4) mounting bolts from side brackets and recycle bracket (♻️ steel)



Seat Removal: (typical)


- Position unit to allow access to the bottom side, use screwdriver (*phillips*) to remove (4) mounting bolts from each seat assembly



Fold Down Sleeper: (con't)

Center Support Removal: (typical)

- With seat panels removed, use screwdriver (*phillips*) and remove (2) mounting bolts from top edge of cross tubes
.....
- Use screwdriver (*phillips*) to remove (1) mounting bolt from bottom outside back frame and remove the support assembly



Center Cross Tubes: (typical)

- Use screwdriver (*phillips*) to remove (4) mounting bolts from end of each cross tube and recycle (steel)



Arm/Outside Back Removal: (typical)

- Use screwdriver (*phillips*) to remove (7) mounting bolts from each bottom inside back (plastic) strip
.....
- Use screwdriver (*phillips*) to remove (3) mounting bolts from each side of outside back assembly
.....
- Use screwdriver (*phillips*) to remove (3) mounting bolts from drawer glide assembly

